

INS-P001



## Installation Instructions (Page 1)

### 2015 Polaris RZR S 900 Front Coilover


King Shocks 12472 Edison Way Garden Grove, CA 92841  
714-530-8701 [www.kingshocks.com](http://www.kingshocks.com)

#### Front Parts List:

2 – 2.5 Front Coilover Shocks (25001-339)

#### Tools Required:

15mm Wrench/15mm Socket  
Floor Jack/Jack Stands



**FRONT:** With the vehicle on level ground, block the rear tires. Using a floor jack, raise the front end and support the frame with jack stands for safety. **NOTE: Never work under an unsupported vehicle.**

1. Remove the factory shocks using a 15mm wrench/socket.



2. Install King Shocks using the factory hardware. Shocks are side specific. Be sure to mount the shocks properly with the reservoirs facing back as shown.



**IMPORTANT:** Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



## 2015 Polaris RZR S 900 Front Coilover

King Shocks 12472 Edison Way Garden Grove, CA 92841  
714-530-8701 [www.kingshocks.com](http://www.kingshocks.com)

3. Your install should look similar to the photo below with the reservoirs towards the rear.



**Double check your install, make sure the shocks are mounted properly and all hardware is tight. Recheck the hardware after 50 miles and periodically after that as part of routine maintenance.**



King Shocks  
12472 Edison Way  
Garden Grove, CA 92841  
[www.kingshocks.com](http://www.kingshocks.com)

**IMPORTANT:** Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.